

Fig 2-1




Fig 2-2






Figure 3-2. Selected Positions.

Fig 2-3



2 Remove magazine.

Fig. 2-4



Do not load with a hot chamber.

2 PULL charging handle all the way back. OBSERVI ejection of case or cartridge. Check chamber for obstruction.

Fig. 2-5

- 3 To lock bolt open, pull charging handle rearward. Press bottom of bolt catch and allow bolt to move forward until it engages bolt catch. Return charging handle to forward. If you haven't before, place selector lever on SAFE.
- 4 Check receiver and chamber to ensure these areas contain no ammo.
- 5 With selector lever pointing toward SAFE, allow bolt to go forward by pressing upper portion of bolt catch.




Fig. 2-6




Figure 3-3. Feeding.

Fig. 2-7




Figure 3-4. Chambering.

Fig. 2-8




Figure 3-5. Locking.

Fig. 2-9




Figure 3-6. Firing.

Fig. 2-10




Figure 3-7. Unlocking.

Fig. 2-11




Figure 3-8. Extracting.

Fig. 2-12




Figure 3-9. Ejecting.

Fig. 2-13




Figure 3-10. Cocking.

Fig. 2-14




Fig. 2-15

(reverse blank)

A-1



Fig. 2-16



Fig 2-17



Fig. 2-18



Fig. 2-20



Fig. 2-19



Fig. 2-21



Fig. 3-1



Fig. 3-2



Fig. 3-3



Fig. 3-4



Fig. 3-5



Fig. 3-6



Fig. 3-7



Fig. 3-8



Fig 3-9




Fig. 3-10



Fig. 3-11



Fig. 3-12



Fig. 3-12a



Fig. 3-13



Fig. 3-14



Fig. 3-15, 3-18, 3-21



Fig. 3-16, 3-19, 3-22



Fig. 3-17



Fig. 3-20



Fig. 3-23



Fig. 3-24




Fig. 3-25



Fig. 3-26



Fig. 3-26a



Fig. 3-27



Fig. 3-28



Fig. 4-5




Fig. 4-6f (far)




Fig. 4-1




Fig. 4-2




Fig. 4-7 and Fig. 4-8




Fig. 4-6c (close)



Fig. 4-6p (perfect)



Fig. 4-11